

Camera	Case	Lens	
		AF DX Fisheye 10.5/2.8G ED	AF-S DX 35/1.8G
D800/D800E	Semi-Soft CF-DC4		
D700	Semi-Soft CF-D700		
D600	Semi-Soft CF-DC5		
D300S/D300/D200	Semi-Soft CF-D200		
D7100	Semi-Soft CF-DC3		
D7000	Semi-Soft CF-DC3		
D90/D80	Semi-Soft CF-DC3		
D70S/D70	Semi-Soft CF-D70		
D5200	Semi-Soft CF-DC2		
D5100	Semi-Soft CF-DC2		
D5000	Semi-Soft CF-DC2		
D3200	Semi-Soft CF-DC1		
D3100	Semi-Soft CF-DC1		
D3000/D60/D40X/D40	Semi-Soft CF-DC1		
F6	Semi-Soft CF-64		

Camera	Case	Lens	
		AF 28/2.8D	AF-S 35/1.4G
D800/D800E	Semi-Soft CF-DC4		
D700	Semi-Soft CF-D700		
D600	Semi-Soft CF-DC5		
D300S/D300/D200	Semi-Soft CF-D200		
D7100	Semi-Soft CF-DC3		
D7000	Semi-Soft CF-DC3		
D90/D80	Semi-Soft CF-DC3		
D70S/D70	Semi-Soft CF-D70		
D5200	Semi-Soft CF-DC2		
D5100	Semi-Soft CF-DC2		
D5000	Semi-Soft CF-DC2		
D3200	Semi-Soft CF-DC1		
D3100	Semi-Soft CF-DC1		
D3000/D60/D40X/D40	Semi-Soft CF-DC1		
F6	Semi-Soft CF-64		

Camera	Case	Lens	
		AF 28-105/3.5-4.5D IF	AF 28-200/3.5-5.6G IF-ED
D800/D800E	Semi-Soft CF-DC4		
D700	Semi-Soft CF-D700		
D600	Semi-Soft CF-DC5		
D300S/D300/D200	Semi-Soft CF-D200		
D7100	Semi-Soft CF-DC3		
D7000	Semi-Soft CF-DC3		
D90/D80	Semi-Soft CF-DC3		
D70S/D70	Semi-Soft CF-D70		
D5200	Semi-Soft CF-DC2		
D5100	Semi-Soft CF-DC2		
D5000	Semi-Soft CF-DC2		
D3200	Semi-Soft CF-DC1		
D3100	Semi-Soft CF-DC1		
D3000/D60/D40X/D40	Semi-Soft CF-DC1		
F6	Semi-Soft CF-64		

Compatible

